

CLEANING AND CARE INSTRUCTION



Cleaning and Care Instruction

Profiles, fittings and glass panels must only be cleaned with mild household cleaners (no microfibre cloths).

Detergents, abrasive cleaners, alcohol or cellulose thinners are not suitable for this purpose.

The mechanical parts of the shower cubicle also need care to maintain their trouble-free function for many years. Regular cleaning and maintenance are decisive factors in maximising their lifespan. The older the deposits on material surfaces, the more difficult to remove.

- Clean and dry the surfaces directly after having a shower.
- Use soft, non-abrasive cloths.
- Important: Highly effective, coarse microfibre may damage the surface.
- Non-abrasive, non-film forming standard household detergents or glass cleaners must be used.
- Please always read the instructions for use of the respective detergents.